




ZDE - Apartado 47 - Pé da Pedreira 2025-999 Alcanede - Portugal T +351 243 409 220 - F +351 243 409 221 geral@fravizel.com - www.fravizel.com

Quick Coupler Simplex (SIMPLEX)



Allows the operator to mechanical release one work tool and engage another quickly. Changes the original coupler system, but maintains the excavation capacity of the machine, because it doesn't increase the space between the accessory and the machine.

Mechanical Quick Coupler (ERM)



Allows the operator to mechanical release one work tool and engage another quickly.

Maintains the original coupler system.

Hydraulic Quick Coupler (ERH)



Allows the operator to hydraulically release one work tool and engage another quickly.

Maintains the original coupler system, the only one with automatic safety system.

Modified Hydraulic Quick Coupler (ERHM)



Allows the operator to hydraulically release one work tool and engage another quickly, sem percas de força de escavação.

Changes the original coupler system, but increases the durability of the same.